



460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

11238.06 1 ½" Diameter Flashlight Bracket Kit Installation Instructions



Step 1: Locate a flat area with enough room to allow mounting of your flashlight. Be sure to space the 2 brackets far enough apart to secure your flashlight at each end.

Step 2: Once mounting location has been determined, mark the 4 holes to be drilled.

Step 3: Using a ¼" drill bit, drill the 4 marked holes.

Caution: Before drilling, be sure there is nothing behind the area being drilled that could possibly be damaged during drilling.

Step 4: Attach the flashlight brackets using the included phillips head screws and nuts.

Step 5: Place your flashlight into the brackets. Installation of your new 1 ½" flash light bracket kit is now complete.