

CB Radio Mount, JK



Components

- 1. CB Mounting Bracket.....(1)
- 2. WM5 Well Nut.....(2)
- 3. M5x20 Philips Head Machine Screw.....(2)
- 4. M5x12 Philips Head Machine Screw.....(2)
- 5. M5 Locking Hex Nut.....(2)

OMIX-ADA® TECHNICAL SUPPORT

PHONE: M-F 8am - 5pm EST 1-800-449-6649 | **EMAIL:** techsupport@omix-ada.com

FOR WARRANTY INFORMATION VISIT: www.Omix-Ada.com



OMIX-ADA, Inc.

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

CB Radio Mount, JK

1. Position sun visors against side windows. Remove center portion of plastic windshield frame cover by gently pulling down until the clips release.



2. For **2007-2010** model JK's: drill out rivets using 3/8" drill bit. Rivets will be replaced with Well Nuts.

For **2011+** model JK's: remove center footman loop by removing (2) Torx Screws.

NOTE: Be careful not to drill too deep, you may damage other side of windshield frame.



3. For **2007-2010** model JK's: insert Well Nuts into newly drilled holes in sheet metal. If drilled holes are too large to snugly fit Well Nuts, secure with small amount of super glue.





OMIX-ADA, Inc.

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

CB Radio Mount, JK

4. For **2007-2010** model JK's: use provided M5x20 screws to install CB Mount and footman loop with CB Mount on outside.

For **2011+** JK's: use factory Torx screws to install CB Mount and footman loop with CB Mount on outside.



5. Replace center plastic windshield frame cover. Install CB Mount, radar detector, or GPS device using M5x15 bolts and Locking Hex Nuts.

NOTE: Make sure any installed devices are secure, and safe. Do not obstruct rear view mirror.

