



460 HORIZON DR. SUITE 100 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

Body Armor, Front Frame Cover; TJ & LJ



Remove the (4) mounting bolts located on the front outer frame of the vehicle (2 per side). Remove the stock cover and replace with the new Frame guard. Reinstall with original bolts.

