

RECON

Supplemental Instruction Sheet for Installing LED Tailgate Bar with White Reverse Lights (Hard Wiring Instructions)

Once you have followed the instructions on the first installation instruction sheet, simply hard wire (aka splice) the white wire coming out of the RECON LED tailgate bar directly to the positive wire of your drivers side reverse light. This wire can be found by simply removing your drivers tail light lens and following the two wires for the reverse light. The negative is typically black. Splice into the other wire which is the positive wire.

**If you have any questions, feel free to contact us:
info@reconaccessories.com - www.GoRecon.com**