



Sky Pods LED Cab Lights

DRILLING TEMPLATES

Cut these templates out carefully and use them to visualize spacing before drilling, and to align holes while drilling. Use the center line to measure distance. Spacing will vary between makes and models. Make sure that before drilling, you cover the area to be drilled with masking tape to prevent damage to paint. PlasmaGlow assumes no responsibility for damage to vehicle due to installation of this product.

