



Silver Bullet

Throttle Body Spacer

PN 46-33002

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make: FORD Trucks and SUV

Model	Year	Engine	Model	Year	Engine
Expedition	04-07	5.4L	F250 Super Duty	04-07	5.4L
F150	04-08	5.4L	F350 Super Duty	04-07	5.4L

1. Disconnect the Evaporative Vent hose from air box. Disconnect the Mass Air-Flow (MAF) harness from air box. Loosen 4 bolts and remove air box from engine.
2. Loosen and remove bolts from throttle body.
3. Install the aFe Silver Bullet throttle body spacer (AIR IN engraving side faces the throttle body), a gasket and throttle body onto intake manifold. Using the washers and longer bolts secure the throttle body to intake manifold. Tighten the bolts to 10 Nm (89 lb/in).
4. Reinstall the air box to engine. Reconnect the EVAP hose and MAF harness to air box.
5. Reinstall the air inlet snorkel to the air box and fender.



Parts List

- 1 aFe Silver Bullet Spacer
- 1 Gasket
- 4 6mm x 70mm bolts
- 4 6mm lock washers

advanced FLOW engineering

252 Granite Street, Corona, CA 92879

Support: 951-493-7100

www.aFePower.com