

Silver Bullet

Throttle Body Spacer

PN 46-35001

Important!

Please verify the parts list and read all instruction steps before you begin installation.

Make:	JEEP						
Model		Year	Engine	Model	Yea	ır	Engine
Cherokee (XJ)		91-01	4.0L				
Grand Cherokee (WJ)		91-04	4.0L				
Wrangler (TJ, Y	J)	91-06	4.0L				

- 1. Loosen and remove air inlet tube from air cleaner assembly. Loosen and remove air inlet assembly from throttle body.
- 2. Remove the four 6mm bolts from the throttle body assembly.
- 3. Install a gasket, the aFe Silver Bullet throttle body spacer (AIR IN engraving side faces the throttle body), and another gasket and throttle body onto intake manifold. Using the washers and longer bolts secure the throttle body to intake manifold. Tighten the bolts to 10 Nm (89 lb/in).
- 4. Reinstall the air inlet assembly on the throttle body. Reattach the air inlet to air cleaner assembly.



Parts List 1 aFe Silver Bullet Spacer 2 Gaskets 4 6mm x 50mm bolts 4 6mm washers

advanced FLOW engineering 252 Granite Street, Corona, CA 92879 Support: 951-493-7100 www.aFePower.com