



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

INSTALLATION INSTRUCTIONS

950-11245
2004
CHEVY COLORADO
&
GMC CANYON
ELECTRIC MIRRORS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

PARTS LIST					
1	RT. Mirror Head	1	LT. Mounting Plate	12	6 MM Nuts
1	LT. Mirror Head	1	Street Scene Emblem		
1	RT Mounting Plate	1	Instruction Sheet		

TOOL LIST
10 MM Socket, Extension, Ratchet, Panel Removal Tool (Optional)

1. Open windows.
2. Remove the mirror trim panel, located behind the mirror and above the door panel by prying the top away from the door. (Use panel removal tool) and pulling up to unhook the bottom.
3. Unplug mirror from connector plug.
4. Remove the three bolts securing mirror to door and remove mirror.
5. Remove the gasket from mirror.
6. Install the mounting plate to mirror head using the nuts provided. Tighten snugly. **DO NOT USE LOCTITE. DO NOT OVER TIGHTEN.**
7. Install the OEM gasket removed in step 5.
8. Install mirror assemble to door. Use three nuts provided and tighten. Plug mirror into harness.
9. Install the trim panel by first inserting the bottom tab into the slot in door and then snapping the top in the hole.