



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11520
DODGE RAM
1994 - 1997
CAL - Vu MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

NOTE: Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST
Ratchet, 6" extension, phillips screwdriver, 10 mm socket wrench, flat blade screwdriver, door panel clip & trim pad removal tool * window crank removal tool, Manual windows only.

1. Roll down windows, using a phillips screwdriver remove the two " door pull cup " screws as well as the retaining screw in the upper front corner of the door panel. Remove door pull cup.
2. If equipped with power windows, remove Power Assist Panel. Release the rear retaining tab by depressing with a screwdriver through the pull cup opening. With the tab released lift the control panel from the rear and remove. Unplug the two connectors from Control Panel.
3. If equipped with manual windows, remove window crank with handle removal tool.
4. Using the Panel Removal Tool. Slide under front edge of door panel, lift to pop off clip, then move around panel with tool releasing all of the clips.
5. Remove nylon clips from inner door and re-install onto door panel.
6. Remove foam mirror plug.
7. Unplug wire harness connector, then remove stock mirror with 10 mm socket and extension.
8. Install Cal-Vu mounting plates to mirror heads (nuts provided) using a 10 mm wrench.
9. Install Cal-Vu mirror to vehicle using nuts provided, then plug in wire harness connector.
10. Install foam mirror plug.
11. Install door panel by lining clips up with holes. Use the palm of your hand to pop in place.
12. On power window models. Plug in the two control connectors and pop in control panel.
13. Install pull cup, then two retaining screws, and the door panel retaining screw.