



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue
Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-11527
2002 - 2004
DODGE RAM
ELECTRIC MIRROR

INSTALLATION INSTRUCTIONS

VERY IMPORTANT ! Read and understand all directions and check the following parts list before starting installation.

NOTE: Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

NOTE: Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep Paint Off

PARTS LIST					
1	RT Mirror Head	1	Instruction Sheet	2	# 4 X 5/8" Screws
1	LT Mirror Head	1	Street Scene Decal	6	6MM Nuts
1	RT Mounting Plate	1	LT Mounting Plate	1	Care For Mirrors

TOOL LIST
10 MM Socket, Extension, Ratchet, Phillips Screwdriver # 2, Flat Blade Screwdriver, Phillips Screwdriver small

1. Open doors and roll down windows.
2. Use a phillips screwdriver to remove the two screws located at the bottom of door panel (Underside).
3. Remove the screw located on the inside corner behind mirror.
4. Using a 10 MM socket, remove the bolt retaining the door handle.
5. Remove the phillips screws behind it.
6. Using a small flat screwdriver remove bezel surrounding the door lock.
7. Lift out window control panel and disconnect wiring by depressing locking tab before removing.
8. Lift the door panel up and out to remove.
9. Depress locking tab on wiring plug and unplug wire loom.
10. Using a 10 MM socket remove the nuts retaining the mirror. Remove mirror and save bolts.
11. Bolt the mounting plate to mirror head using the nuts provided. While routing the wires through the hole.
12. Using the two # 4 X 5/8" screws provided, Attach the wire plug to the mounting plate. **DO NOT OVER TIGHTEN.**
13. Remove gasket from OEM mirror and install on SSE mirror.
14. Attach mirror to door using the bolts removed in step 10.
15. Re-install door panel in revers order of removal.