



# STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, Ca. 92626

Phone (714) 426-0590 Fax (714) 426-0591

**950-11620**  
**97 - 2000**  
**DODGE DAKOTA**  
**&**  
**DODGE DURANGO**  
**CAL - Vu MIRROR**

## INSTALLATION INSTRUCTIONS

**NOTE:** Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

**NOTE:** Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

**NOTE:** Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

**NOTE:** Do Not Use Loctite On Threads. Warranty Will Be Void If Used

**NOTE:** Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

**NOTE:** Do Not Over Tighten Nuts, Mounting Brackets Will Crack

**NOTE:** If Painting Mirrors Tape Over Threads To Keep Paint Off

**VERY IMPORTANT !** Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	12	6 mm Nuts
2	Mirror Plates	1	Street Scene Decal		

TOOL LIST
3/8" ratchet, 6" extension, 8mm socket, small flat blade screwdriver, phillips screwdriver, 10mm wrench # 30 torx socket, window crank removal tool, manual windows only.

1. Roll down windows and using a phillips head screwdriver remove the retaining screw in the upper front corner of the door panel. Remove the two #30 torx screws behind the door release handle. Remove phillips screw located at the rear bottom corner of door panel.
2. If equipped with power windows, remove Power Assist Control Panel. Insert the small screwdriver at top center of panel to release the top clip. Release bottom clip and remove panel. Unplug electrical connectors.
3. If equipped with manual windows, remove window crank with removal tool.
4. With palm of hand, gently tap door panel upward to release the integrated panel retaining clips. Lift up and remove door panel. Unplug mirror switch connector located on inner door panel.
5. Unplug wire harness connector and remove the three 10 mm nuts securing the stock mirror. Remove the stock mirror.
6. Install Cal-Vu mounting plates to mirror heads ( nuts provided ) using a 10mm wrench.
7. Place foam gasket over Cal-Vu mounting plate. Install Cal-Vu mirror to vehicle using stock hardware. Take care to keep foam gasket underneath edge of mirror plate. Plug in mirror connector into wire harness.
8. Plug mirror switch connector into wire harness, then install door panel by lining up hooks on the door panel with slots in door and sliding door panel down.
9. Install remaining components in reverse order of disassembly.