



STREET SCENE EQUIPMENT, INC.

365 McCormick Avenue

Costa Mesa, CA. 92626

Phone (714) 426-0590 Fax (714) 426-0591

950-27935
 2003 - 2005
CHEVY SILVERADO
GMC / SIERRA
ELECTRIC MIRRORS
WITH FACTORY HEAT
AND FACTORY SIGNAL
CAL-VU MIRROR

INSTALLATION INSTRUCTIONS

NOTE: Please check year, make, and model against application part number. Be sure both mirror heads and mounting plates are left & right side before painting. Parts that have been painted are not eligible for return.

NOTE: Check Your Mirror Plugs To Make Sure They Plug Into Your wire harness before painting, If painted warranty will be void.

NOTE: Mirrors are designed for specific year vehicles. Although mirror may appear to be the same, the electrical connectors will vary year to year. If your mirror does not plug into your factory wire harness, please check your part number and application guide.

NOTE: Do Not Use Loctite On Threads. Warranty Will Be Void If Used

NOTE: Do Not Attempt To Remove Glass For Paint Damage Could Occur And Glass Will Break.

NOTE: Do Not Over Tighten Nuts, Mounting Brackets Will Crack

NOTE: If Painting Mirrors Tape Over Threads To Keep paint Off

VERY IMPORTANT ! Read and understand all directions, then check the following parts list before starting installation.

PARTS LIST					
2	Mirror Heads	1	Instruction Sheet	6	Six mm Nuts
2	Mirror Plates				

TOOL LIST
10 MM Socket, 7 MM Socket, 5 MM Socket, 11 MM Socket, Ratchet, Extension, Flat Blade Screwdriver, # 20 Torx

1. Roll down windows prior to removing door panels.
2. Remove the bezel surrounding the manual door lock, located in the center of door panel just below the door glass. Remove the screw located behind it. NOTE: direction of manual door lock.
3. Remove the hex head screw located in the arm rest portion of the door panel.
4. Remove the bezel surrounding the door release handle.
5. On late 2004 models and 2005 models, remove the round plastic cover over the # 20 torx screw located at the outer center edge of door panel and then remove screw. Pry out the push in fastener across the panel at the front edge. Be careful not to damage the fasteners for use when reassembling.
6. Lift up on door panel to remove, while reaching in from behind and disconnecting courtesy light.
7. Disconnect mirror plugs, blue and black by depressing the locking tabs. It is not necessary to remove the door panel from vehicle. If you would like to remove the door panel completely disconnect the other plugs. The larger black plug requires the grey arm on it to be released and pulled back in an arc like fashion.
8. Peel back the upper corner of the plastic protector below the mirror on door.
9. Unsnap the mirror wire retainers from doors.
10. Remove the foam filler located in the triangular opening behind mirror.
11. Remove the three attaching nuts and remove mirror. Save nuts for re-assembly.
12. Remove gasket from OEM mirror and install on Street Scene Mirror.
13. Install mirror in reverse order of removal.