

# INSTALLATION INSTRUCTIONS

**DO NOT EXCEED PRODUCT RATING OR TOW VEHICLE LAMP LOAD RATING, WHICHEVER IS LOWER**

## 55382 APPLICATIONS

Make	Model
Jeep	Liberty

## WIRING LOCATION GUIDE


### SUVS, MINI & FULL-SIZED VANS (S)

Representative vehicle shown below

**S1** - Behind driver side taillight housing

**S2** - Behind passenger side taillight housing

## VEHICLE-TO-TRAILER WIRING HARNESS



## NOTE

All steps must be followed to ensure the CURT wiring harness will function properly. Once installed, test for proper function by using a test light or connecting a properly wired trailer.

## TOOLS NEEDED

- T-20 Torx bit
- Phillips screwdriver

## WARNING

The battery connection must be fuse protected, 10 amp max. Exceeding the product rating can cause loss of warranty, overheating and potential fire. Do not exceed product rating or tow vehicle lamp load rating, whichever is lower.

Signal Circuits - 3.0 amps per side

Tail / Running Circuits - 5.0 amps total

Check vehicle owner's manual or contact the vehicle manufacturer for more information.

# INSTALLATION

## Step 1

Locate vehicle battery on the driver side under the hood and disconnect the negative battery terminal.

## Step 2

Open the vehicle tailgate. Locate the screws holding the driver and passenger side taillights in place. The screws are located by the hinge on the inside of the taillight (A,B).

## Step 3

Starting on the driver side, remove the two screws using a T-20 Torx bit. Loosen the taillight by gently pulling rearward and out. Take care not to damage the alignment tabs (C).

## Step 4

Locate the vehicle taillight wiring harness connectors. The connectors will be similar to those on the CURT wiring harness. Separate the connectors from the taillight housing taking care not to damage the locking tabs.

## Step 5

Insert the CURT wiring harness end with yellow wire between the separated connectors. Make sure the connectors are fully inserted with locking tabs in place.

**WARNING:** Check for miscellaneous items that may be hidden behind or under any surface before drilling to avoid damage and / or personal injury.

## Step 6

Locate a suitable grounding point near the connector such as an existing screw with nut in the vehicle frame or drill a 3/32" pilot hole for the provided screw. The area should be free of rust, dirt and paint. Secure the white ground wire using the ring terminal and provided screw.

## Step 7

Route the CURT wiring harness end with the green wire down the opening behind the taillight on the drivers side (D). Route harness containing the green wire underneath the vehicle up through the opening behind the passenger side taillight.

## Step 8

Locate a flat spot inside the vehicle, near the taillight. Adhere the black converter box using the provided double-sided tape.

## Step 9

When in use, route the 4-flat to the center of the vehicle. When not in use, roll up and store in a convenient, out of the way location. Secure any loose wires with the provided cable ties.

## Step 10

Reinstall all items removed during install and reconnect negative battery terminal. Install the provided 4-flat dust cover to help prevent corrosion.

