

WIND TAMER ***SUNROOF WIND DEFLECTOR***

INSTALLATION INSTRUCTIONS

BEFORE INSTALLATION: Trial fit the Wind Tamer to vehicle to insure you have the correct size.

- 1** Wipe the area where the adhesive strip will contact the roof with the alcohol pad provided. Allow the alcohol to dry completely.
- 2** Peel the red backing off the two small pieces of adhesive strip at the left and right side of the Wind Tamer. Peel off 2 inches of adhesive backing from the center adhesive strip. (Fig 1)
- 3** Position the Wind Tamer on the roof so that it is centered left and right on the sunroof opening and the adhesive strip is flush with the front edge of the sunroof gasket (Fig 2)
- 4** Press down on the left and right side of the Wind Tamer to adhere the two smaller pieces to the roof, then secure center strip starting with the exposed section of adhesive peeling away the backing as you go. (Fig 3)

