

RECON

Supplemental install instructions for
part #26415X & 26416X

XTREME TAILGATE LIGHTBARS

First connect the flat four and reverse wire as stated in the included instruction manual then follow the supplemental instructions below:

The remaining **RED** wire needs to be connected to a ‘hot’ 12V power source. Most late model trucks have a hot wire located in the 7 pin trailer connector where you can splice the **RED** wire into. If your truck doesn’t have a 7 pin trailer connector, you can connect the **RED** wire to any “hot” 12V power source located on the truck.

**If you have any questions, feel free to contact us:
info@reconaccessories.com - www.GoRecon.com**