



Step 1. Undo ALL 3 bolts on inside wall of truck bed



Step 2. Attach rails to side wall. Make sure rails are positioned hard up against cab wall. Use smaller diameter screws in middle and larger at front.



Step 3. position cover squarely on rails. Make sure the cover sits against cab and on top of tailgate.



Step 4. Push Cover HARD up against cab. Rubber seal should be compressed slightly. Drill a hole with an 11/32" bit through the plates that extend out of your Bakflip rails. (2 on each side)



Step 5. Push provided bolts through holes and plate and tighten under cover, using provided nuts and washers.



Step 6. Attach provided shocks to connectors on cover and rails. Attach drain tubes.