

54938
51938
12-13 TOYOTA
TACOMA



54938
51938
12-13 TOYOTA
TACOMA

12-13 TOYOTA TACOMA

Upper Class Mesh Grille

Install time: 35 Mins.

TOOLS REQUIRED:

3/16 Drillbit
Screwdriver
Dyegrinder

PARTS LIST:

(1) Mesh Grille	(2) 135' 1/2 Flange Brackets
(7) #8 3/4 Screws	(2) 6/32 Nylon Lock Nuts
(7) #8 Flatnuts	

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE ATTEMPTING INSTALLATION.

- Remove 2 Bolts and 1 Clip along the top of the Factory Grille. (Fig.1)
- Unclip 8 Clips along the Bottom of the Factory Grille to Remove.
- With a Dyegrinder, cut along the Factory Grille to remove Grille. (Fig. 2) (Do not remove the long Black Tab along the bottom of the Factory Grille)
- Place Mesh Grille onto the Factory Grille Shell. (Fig. 3)
- Securely have in place the Mesh Grille. (make sure it fits properly) (Fig. 4)
- With a 3/16 Drillbit, Drill through the opening tabs on the Mesh Grille. (Fig. 5)
- Insert the #8 Screws to Thread a Flatnut. (Fig. 6)
- Place the Flange Brackets on the Threaded Studs on the Mesh grille and Tighten with provided Nylon Lock Nuts. (Fig. 7)
- Place Grille Back onto the Truck.

Installation Complete

