



INSTALLATION INSTRUCTIONS FOR LED DAYLINER

2014-Up GMC Sierra LD & 2015-Up GMC Sierra HD #270115

Congratulations on your purchase of a high quality PUTCO product.

Should you need any application or technical assistance feel free to call us at: 1-800-247-3974

Monday-Friday 8:00 a.m.- 5:00 p.m. (Central Standard Time)

Contact your PUTCO dealer for other quality accessories.

PUTCO Inc. - Des Moines, Iowa 50313

Please read all instructions before beginning installation and be sure to check to see that all parts and hardware are included.

Parts List

Description	Qty
Driver Side LED Dayliner	1
Passenger Side LED Dayliner	1
Scotch Lock Inline Tap	4
Alcohol Prep Pad	1

Tools Needed for Installation

Wire Cutters
Electrical Crimping Tool
Wire Strippers
Isopropyl Alcohol
Non-Abrasive Towel

Step 1: Verify kit contents.

Step 2: Clean the surface of the headlights using 90% Isopropyl alcohol where the Putco LED Dayliner Lights will be installed.

ASSEMBLY NOTE: *The power cord will run between the grille and headlight. Ensure there are no moving parts that may cause damage to the cord.*

Step 3: Align the Putco LED Dayliners with the head lights. The Dayliners will fit vertically at the inside edge of the headlight.

Step 4: Remove the protective backing to expose the tape and apply to the headlight by applying constant pressure for 30 seconds.

Step 5: Run the gray wire between the grille and headlight.

Step 6: Run the gray Putco LED Dayliner wire behind the headlight to the factory daytime running light wiring harness.

(NOTE: You will have extra wire from the Putco Dayliner light so remove any excess wire that is not needed.)

Step 7: Tap into the factory daytime running light harness behind either headlight. When you look at the back of the headlight from the engine compartment side, you will see a large multi-pin connector that is clipped onto the back side of the headlamp and has wires leading into the headlamp. Both Drivers and Passengers side Dayliners can be wired to this headlamp by stripping the red Dayliner wires and twisting them together and also doing the same for the black wires.

(CAUTION: DO NOT CUT THE VEHICLES FACTORY WIRES IN HALF!!!)

Step 8: Attach the Putco Red (+) wire to the Factory Brown (+) wire and the Putco Black (-) wire to the Factory Black (-) wire using the supplied scotch locks and your electrical crimping tool.

Step 9: Verify everything is connected securely and turn the vehicle on to test the LED Dayliner Light.

(NOTE: Your Putco LED Dayliner Lights will only operate when the vehicle is on and the daytime running lights are on or when the low beams are in use. They will not operate with high beams.)

Note: If your lights do not turn on verify the connection between the Factory and Putco wiring is secured properly.

INSTRUCTION # IN270115 060914JS

LIMITED WARRANTY

Putco guarantees its Stainless Steel and Aluminum products against defects in workmanship and material for as long as you own your vehicle. Black products have a 90 day warranty on the painted surface. Any defects resulting from faulty material or workmanship will be warranted by Putco and repaired or replaced at our discretion. Putco assumes no extra labor costs. Damages caused by freight carriers, improper installation, misuse, collision, or neglect will not be warranted by Putco.