

# TONNEAU COVER SPECIAL INSTRUCTIONS

For: Chevy/GMC Step Side Box-Special Side Rail Installation #220

This kit substitutes the use of eight #12 x 3/4" AB stitch screws in place of the C-clamps normally used on this application. **REMEMBER TO USE PROTECTIVE EYEWEAR**

- STEP 1:** Hold side rail in position against box as shown in owners manual. Make sure the rail is where you want it.
- STEP 2:** Then use a drill or screw gun with 5/16 hex socket and turn screws in. There is no need to drill a hole. Applying pressure and speed with the drill or screw gun will drive the screw through, providing maximum gripping power.  
NOTE: The holes in the rails are 1/4 x 5/8" slotted vertically, this allows for adjustments.

