

Installation Instructions

FITS: 97-06 Jeep Wrangler TJ

Rear Fender Flare

TOOLS NEEDED

| | | |
|---------------------|--------------------|-------------------|
| 8mm Wrench & Socket | 9/64" Allen Wrench | Adjustable Wrench |
| Pliers | | |

COMPONENTS & HARDWARE

| # | QTY | | # | QTY | |
|---|-----|--------------------------|---|-----|--------------------------|
| A | 1 | Rear Fender Flare (Pair) | B | 12 | M6x25mm Button head bolt |
| C | 24 | M6 Flat washer | D | 12 | M6 Lock nut |



Please take a few minutes to read and thoroughly familiarize yourself with the installation procedures outlined in this manual. Following the steps as outlined will save you time and help reduce mistakes. Once the instructions are reviewed, if you feel that you are not capable of safely installing the parts seek the help of a qualified installation expert to help you complete the job. The manufacture is in no way responsible for any personal injury or vehicle damage that may occur during the installation.

California Proposition 65 Warning!

This product may contain one or more chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. For more information go to www.P65Warnings.ca.gov.

Removing Factory Fender



Step 1.

Pull back the plastic inner fender liner. Remove the (8) - 8 mm screws holding the fender are to the body. Insert the adjustable wrench behind the body to hold the square plastic nut while removing the 8mm screw with a socket wrench.

Installing New Fender



Step 2.

Insert bolts through flare and jeep body and hand tighten with lock nuts. (You may need to pull inner fender liner down to gain access to the back of the bolts to install the nuts)



Step 3.

Installation is complete, repeat same steps for opposite side.