



SPYDER

WWW.SPYDERAUTO.COM

INSTALLATION GUIDE:

PRO-YD-FF15009 CCFL&HALO(ALL COLORS)

Tools Required

10mm Socket wrench/ratchet

Phillips-Head Driver

Please Note

If you are unfamiliar with the installation processes, professional installation is highly recommended.



1) Open your hood and locate the plastic Phillips screw that is holding the headlight shroud. Once the plastic Phillips screw has been removed with a Phillips screw driver, fold the shroud back to access the (3) 10mm bolts.



2) Once the shroud has been folded to the side, you will be able to access the (1) 10mm bolt behind it. Remove (2) 10mm nuts, shown on top. Unscrew these bolts and set aside for later use, as you will reuse these bolts to secure your new Spyder light.



3) Next, gently pull outwards from the back of the headlights to get it free. Still attached will be (3) headlight harness. Disconnect the light harness while retaining the side marker light and turn signal light bulb (will be reused later) which will come out by turning them counter-clock wise. Set OEM assembly aside.



4) Reinstall the headlight harness into your Spyder light onto your vehicle with your 10mm bolts and phillups screw on the shroud that you have removed from the beginning Please follow the instructions you have received in the box to wire up the halos. Close your hood and enjoy the new set of Spyder headlights.



For further help with installation, please watch our installation video. Follow the direct link below to our YouTube channel for more information.
<http://www.youtube.com/watch?v=LZexjd1ptD4>

Disclaimer

Spyder Auto Installation Guide is not liable for damages, injuries, and death while installing the product. This is intended to be an installation guide, to cut down installation time for you. We have no responsibility for improper installation, if you do not know how to install, please have a professional install it.