



Installation Instructions **P/N 69998** **YJ Windshield Uprights**

Kit Contents:

- 1 - Driver Upright
- 1 - Pass Upright
- 8 - #8 x 1/2" Screws

Required Tools:

- Phillips Screw Driver
- Drill motor
- 1/8" Drill Bit

Upper Door Windshield Insert Installation

1. Locate Driver Upper Door Windshield Insert and position it on the side of the windshield. With Upper Door Windshield Insert in position mark the vehicle through the holes (Figure 1).
2. Remove Upper Door Windshield Insert and place aside. Carefully drill 1/8" holes on the marked locations.
3. Re-position Upper Door Windshield Insert and secure it by using the included (4) - #8 x 1/2" Sheet Metal Screws (Figure 2).
4. Repeat steps for opposite side.



Figure 1



Figure 2