Part # 3510,35100- 1987-95 Ford F-Series Truck 302

Part # 3511,35110- 1987-95 Ford F-Series Truck 351

Tuned Shorty Headers



Special Tools

Install Time:

Required:

Approximately 2 Hours 30 Mins

 No special tools required

Difficulty:

3 out of 5

Follow these instructions carefully to ensure correct fitment and operation.

STEP 1

 Disconnect the negative battery terminal and place the vehicle on sturdy jack stands.

STEP 2

 Carefully disconnect the spark plug wires, heat shields and engine bracket to allow access to the exhaust manifold bolts. (The heat shields and bracket will not be re-used).

STEP 3

 Disconnect the EGR tube attached to the fitting on the passenger side exhaust manifold. This tube will be re-installed on the BBK Header.

STEP 4

 From under the truck, carefully remove the 4 collector nuts attaching the manifolds to the Y-Pipe.

STEP 5

 Remove all of the exhaust manifold bolts and remove them from the vehicle. Clean the old gasket material from the head surface. <u>NOTE!!!</u> Dipstick tube must be removed with the exhaust manifolds and the mounting flange side ground down to fit under the new header bolt.

STEP 6

 Install the headers and bolts. Be sure to reinstall the dipstick tube with the header. Tighten all the bolts.

STEP 7

 Re-install the spark plugs, wires, EGR connections and any other parts removed for the install.

STEP 8

• From under the truck, reconnect the Y-Pipe assembly. Use the supplied flat washers.

STEP 9

 Reconnect the negative battery terminal and start the engine to check for any leaks. Header bolts should be rechecked after a few hundred miles of driving.



Join our Facebook page www.facebook.com/bbkperformance





Check us out on Youtube www.youtube.com/bbkperformance

WWW.BBKPERFORMANCE.COM

▼)

For any questions, email us: tech@bbkperformance.com

installation instruction

1