

Step 1:

Lower Tailgate and remove Four Factory Bolts at along the rail of the truck.



Step 2:

Line up Advantage rails to factory bolt holes.



Step 3:

Insert Advantage Bolts into proper Holes. Tighten with keys provided.



Step 4:

Apply Cover to Bed Of truck



Step 5:

Clamp cover firmly to new rails.

