

Part#: **124026** 

Product: Transfer Case Drop

Application: 1993-1998 Jeep Grand Cherokee ZJ

491 W. Garfield Ave., Coldwater, MI 49036

Phone: 517-279-2135

Web/live chat: www.bds-suspension.com

E-mail: tech@bds-suspension.com

## READ AND UNDERSTAND ALL INSTRUCTIONS AND WARNINGS PRIOR TO INSTALLATION OF SYSTEM AND OPERATION OF VEHICLE.

**SAFETY WARNING** BDS Suspension Co. recommends this system be installed by a professional technician. In addition to these instructions, professional knowledge of disassembly/reassembly procedures and post installation checks must be known.

## INSTALLATION INSTRUCTIONS

- 1. Support the transfer case with a hydraulic jack.
- Loosen but do not remove all four transmission crossmember bolts.
- **PARTS LIST** Part # Otv Description YJTC5 Transfer Case Drop Spacer 703 **Bolt Pack Bolt Pack 703 Description** Qty 10mm-1.50 x 50mm bolt class 10.9 clear zinc 4 10mm flat washer clear zinc 4 4 10mm helical spring lockwasher clear zinc
- 3. Remove the two passenger's side crossmember bolts. Lower the crossmember just enough to be able to place the provided drop spacers (YJTC5) at the four mounting holes. Loosely attach the crossmember and spacers with two 10mm x 50mm and two flat and lock washers.
- 4. Repeat spacer installation on the driver's side.
- 5. With the spacers installed, remove the bolts one at a time and apply loctite to the threads. Install the bolts and torque to 30 ft-lbs.

rev. 5/21/2013 124026 Page 1