

420 N. Grove, Richardson, TX 75081
Tele: (800) 527 - 4345 Fax: (800) 442 - 5263
Web site: www.goindustries.com
E-mail: sales@goindustries.com

Mud Flaps
Installation Instructions
70732
Chevy/GMC '01 - '07

1. Separate driver's and passenger's main bracket (Note: ear tab on bracket must point toward rear of truck). Position ear tab against pinch weld.
2. Remove factory bolt from inside of fender well. Replace with supplied metric bolt, this will attach support brace for bracket. Attach main bracket to support brace. Main bracket should be level and straight with body of truck.
3. Mark hole to be drilled in pinch weld to secure main bracket to bed of truck.
4. Attach mud flaps to brackets, level and tighten all bolts at this time.

