

Mud Flaps
Dodge Ram '86-'93 Dually
728

Contents:

- 1 pair of 728B (brackets)
- 1 pair of 725F (mud flaps)
- 1 70730 Bolt kit
- 1 Mud Flap bolt kit

1. Put 725F to the brackets using side of bracket with 3 holes that match holes on 725F. Use mud flap bolt kit to attach flap to bracket.
2. Place bracket inside of fender well adjust flap to center behind dually tires. Flap should be 4 to 6 inches off of ground depending on vehicle and customer preference. Flap should be at least 2 inches or more from the tires. Mark fender well to drill holes to attach bracket to fender well. Use only the metal part of fender well. (Do not put bolts through only plastic. Make sure bolt goes through metal.)

