

HUSKY **WeatherBEATER™** **Custom Vehicle Floor Protection**

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater® Floor Liner from Winfield Consumer Products. Your new front floor liners are custom molded to fit your Toyota Tacoma equipped with an automatic transmission. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, do not remove the factory-installed carpeting.

Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR YOUR TOYOTA TACOMA FRONT FLOOR LINERS-MODELS WITH AN AUTOMATIC TRANSMISSION



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE INSTALLATION OF YOUR TACOMA FRONT LINERS, MOVE THE FRONT SEATS TO THEIR MOST REARWARD POSITION. WITH THIS DONE, INSTALL THE LINERS POSITIONED AS SHOWN ABOVE. THE DRIVER'S SIDE LINER ATTACHES TO THE FACTORY TWIST-LOCK MAT RETAINERS LOCATED IN THE VEHICLE FLOOR PAN. TAKE CARE TO MAKE SURE THE LINER IS SECURELY AFFIXED. ONCE LINERS ARE IN PLACE, REPOSITION THE SEATS AS DESIRED.

THE PASSENGER SIDE LINER IS SECURED IN PLACE WITH TWO (2) INCLUDED CLIPS. TO INSTALL THESE CLIPS, PLEASE REVIEW THE INSTRUCTIONS ON THE BACK OF THIS PAGE.

INCLUDED IN YOUR PACKAGING YOU WILL FIND TWO (2) COMPONENT BAGS, EACH WITH A FASTENER DESIGNED TO AID IN SECURING THE PASSENGER SIDE LINER IN PLACE. THE CLIPS WILL PROVIDE A WATER TIGHT SEAL SO MOISTURE WILL NOT PASS THROUGH TO THE FLOOR BELOW. TO INSTALL THE CLIPS, FIRST REMOVE THEM FROM THE BAGS AND UNSCREW THE CAP FROM THE BASE (SEE IMAGE 1 BELOW). NEXT, INSERT THE THREADED PORTION OF THE BASE INTO THE HOLE IN THE DRIVER'S SIDE LINER, INSERTING IT FROM THE BACK SIDE OF THE LINER (SEE IMAGE 2 BELOW). WITH THIS DONE INSTALL THE LINER IN THE VEHICLE AND, USING A COIN, SCREWDRIVER OR SIMILAR TOOL, SCREW THE BASE OF THE FASTENER INTO THE CARPETING (SEE IMAGE 3). LASTLY, AS SHOWN IN IMAGE 4, INSTALL THE CAP ONTO THE BASE. TIGHTEN EACH CAP UNTIL IT MEETS RESISTANCE, DO NOT OVER TIGHTEN.

