

CARE AND USE INSTRUCTIONS

Thank you for selecting a WeatherBeater® Floor Liner from Winfield Consumer Products. Your new 3rd seat floor liner is custom molded to fit your Toyota Highlander. The liner is made to take the place of your factory floor mats. *For correct fit, it is necessary to remove the factory floor mat before installing your new floor liners*. However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409[®] or Glass Plus[®] work well. Use of Armor All[®], Son-of-a-Gun[®] or similar items is discouraged as these products make the liners slick.

INSTALLATION INSTRUCTIONS FOR YOUR TOYOTA HIGHLANDER THIRD SEAT FLOOR LINER



TO EASE INSTALLATION OF YOUR $3^{\rm rd}$ SEAT HIGHLANDER FLOOR LINER, FIRST SLIDE THE $2^{\rm ND}$ ROW SEATS FORWARD. WITH THIS DONE, INSERT LINER IN VEHICLE THEN REPOSITION THE $2^{\rm ND}$ ROW SEATS AS DESIRED. THE CENTER EXTENSION OF THE LINER PROVIDES WALKWAY COVERAGE FOR $2^{\rm ND}$ ROW BUCKET SEAT MODELS. THIS EXTENSION TUCKS BEHIND THE BACK OF THE $2^{\rm ND}$ ROW LINER.