

# Running Board Instructions

## 1061

( 95-99 ) Tahoe / ( 96-99 ) Yukon

( 92-99 ) Suburban

( 88-98 ) 1500 CK Pickup Reg/Ext Cab

( 88-00 ) 2500/3500 CK / Pickup Reg/Ext/Crew Cab

( Minor Drilling Required )

### INSTALLATION PACKAGE

Running Board	2
Installation Instructions	1
Bracket	10
Straps	10
Support Plate	10
Bolt Pack	2

### Necessary Tools

Ratchet wrench with 1/2" socket  
 Combination wrench  
 Variable speed drill w/ 3/8" hex head drive  
 Safety glasses

### Bolt Pack Brackets

5/16" x 2" Hex Bolt	10
5/16" x 3/4" Hex Bolt	10
5/16" Flat washer	20
5/16" Serrated Flange Nut	20
3/4" Self Tapping Tec Screws	10

### Bolt Pack Running Boards

5/16" x 3/4" Hex Bolt	20
5/16" x 3/4" Serrated Flange Nut	20

### STEP ONE: Determine proper bracket placement Fig A

- 1) Equally space 1st (3) brackets on front floor pan weld, and the 4th & 5th on the back two welds.
- 2) Drop 2" bolt through bracket and into hanger bracket, hand tight
- 3) Do this with all brackets putting them in proper areas

### STEP TWO: Attaching twist trap to bracket and rocker panel Fig B

- 1) Bolt the twist straps to the side of bracket using 3/4" bolt, And flange nut.
- 2) Slide bolts down underside of board to line up with brackets. You will only need one bolt to hold board to bracket. Use two if slot and bracket line up.
- 3) Tilt board back and slide up under body letting the rear bolts fall into slots first then the front bolts.
- 4) Hand tighten the board to the brackets using 5/16" lock nuts
- 5) Slide board in or out to desired location
- 6) Tighten down lock nuts under running board

### STEP THREE: Tec screw strap into rocker panel

- 1) Push board tight against vehicle and tec screw strap into rocker panel using top hole of strap.
- 2) Go back to the hanger brackets [fig A] and tighten.
- 3) Check that all brackets are tight before stepping on boards.

