

iRunning Board Installation Instruction

REV: 20180501

Part#: IB20RJE4

Application: For 1995-2004 Toyota TACOMA Extended Cab(4WD Or Prerunner 2/4WD)

PARTS LIST:

| Item | QTY | Description | Item | QTY | Description |
|------|-----|--------------------------------------|------|-----|---------------------|
| #01 | 2 | Step Board (Used for left and right) | #06 | 8 | M8 Nylon Lock Nut |
| #02 | 8 | Mounting Brackets | #07 | 16 | M6 Square Head Bolt |
| #03 | 8 | M8x20mm Hex Bolt | #08 | 16 | M6 Nylon Lock Nut |
| #04 | 16 | ST 6.3-22 Self Tapping Screw | #09 | 16 | M6 Flat Washer |
| #05 | 16 | M8 Flat Washer | | | |



Mounting Brackets

INSTALLATION INSTRUCTION:

- 1. REMOVE CONTENTS FROM BOX. VERIFY ALL PARTS ARE PRESENT. READ INSTRUCTIONS CAREFULLY BEFORE STARTING INSTALLATION.(Fig 1).**
- 2. Drill 8mm holes in pinch weld as shown(Fig 1).**
- 3. Attach mounting brackets as shown(Fig 2,3 and 4).**
- 4. Insert square head bolts as shown (4 per slot,8 per Step board/Running board)(Fig 5).**
- 5. Attach Step board/Running board to brackets as shown.Align and tighten(Fig 6).**
- 6. Repeat Installation for other side.**
- 7. INSTALLATION IS COMPLETE.**

To protect your investment, wax this product after installing. Regular waxing is recommended to add a protective layer over the finish. Do not use any type of polish or wax that may contain abrasives that could damage the finish.

For Polished Finishes: Aluminum polish may be used to polish small scratches and scuffs on the finish. Mild soap may be used also to clean the Running Board.

For black finishes: Mild soap may be used to clean the Running Board.

iRunning Board Installation Instruction

REV: 20180501

Part#: IB20RJE4

Application: For 1995-2004 Toyota TACOMA Extended Cab(4WD Or Prerunner 2/4WD)

