



BX1810 Installation Instructions 1986 1/2 - 95 Nissan Pickup 4WD

1. Read the General Instruction Sheet included with this baseplate.
2. The baseplate mounts to the front underside of the vehicle using six bolts, two existing and four supplied.
3. Remove the tow hook from the passenger's side of the vehicle. Note that there are similar bolt holes on the driver's side. Inspect the bolts for reuse. See General Instruction Sheet.
4. Position the baseplate aligning the baseplate holes with the holes in the frame where the tow hook bolts were. Hand start the bolts that were removed and the 12mm bolts with the lock washers provided. Use Loctite, but do not tighten yet.
5. Insert the small raised portion of the tie down clamps into the oblong hole of each tie down bracket. Install a 1/2" bolt through the clamp, tie down bracket, and baseplate. Loosely secure with the 1/2" nuts and lock washers provided.
6. When all bolts align, apply Loctite and tighten securely.
7. The dimensional variations between otherwise identical vehicle can be considerable. While the location and size of the holes in the baseplate were designed to allow easy installation, it may be necessary to file a hole slightly to allow a bolt to clear.
8. Install the tow bar and safety cables according to the instruction included in their packages.
9. Do not substitute other devices if the tow bar pin and clip are lost.
10. **DEALERS AND INSTALLERS:** BE CERTAIN THE USER RECEIVES THE INSTRUCTION SHEET.

Automatic

Tools Required

17mm socket	3/4 socket
19mm socket	3/4 open end wrench

Parts List

Ref. No.	Qty.	Part No.	Description
1	1	61-3789	Main Baseplate Assembly
2	2	61-3790	Tie Down Spacer
3	2	201-0051	1/2-13 x 1 1/2 Hex Bolt, Grade 5
4	2	201-0411	12mm-1.25 x 40mm Hex Bolt, Grade 8.8
5	2	202-0005	1/2-13 Hex Nut
6	2	203-0012	1/2 Lock Washer
7	2	203-0105	12mm Lock Washer
	2	226-0049	Baseplate safety Cable, 36" CL IV (Not Shown)
	4	229-0512	Quicklink, 1/2, ZP (Not Shown)

