

NOTE: Read before install. Carven Exhaust Inc, recommends professional installation for all of our products. Install products at your own risk.

Allow exhaust system temperatures to cool down, 2-3 hours after vehicle has been running is recommended. Refer to power tools and equipment manuals for proper safety instructions.

Safety wear is recommended, serious injuries and burns can occur if proper safety precautions are not taken. If you have any questions please contact info@carvenexhaust.com or (951) 817-5101.

Carven Exhaust is not responsible for performance on install nor warranty. Customer to verify due diligence regarding install and warranty.

For more install instructions & tips please visit our YouTube channel @ Carven Exhaust.

Clamp Specs: Place top of clamp over non perforated section of tube, then slide clamp down to the slit section. Torque clamp bolt to 65LBS.



Step 1:

- Be sure to leave OEM exhaust system bolted and tightened securely before cutting (all proper safety precautions should be taken)



Step 2:

- Using a Sawzall, cut 1" behind the muffler section towards the rear of the truck
- Unbolt at flange and remove stock muffler



Parts Included:

- 3" band clamp QTY: 1
- Hex Bolt/Nut QTY: 2 EA

Step 3:

- Use OEM flange gasket & bolt on new system
- Insert cut OEM tube into the new kit and slide 3" clamp into place



Step 4:

- Remove OEM tips and install Carven signature tips (if purchased)
- Make any adjustments to tip/muffler section

