



NOTE: Read before install. Carven Exhaust Inc, recommends professional installation for all of our products. Install products at your own risk.

Allow exhaust system temperatures to cool down, 2-3 hours after vehicle has been running is recommended. Refer to power tools and equipment manuals for proper safety instructions.

Safety wear is recommended, serious injuries and burns can occur if proper safety precautions are not taken. If you have any questions please contact info@carvenexhaust.com or (951) 817-5101.

Carven Exhaust is not responsible for performance on install nor warranty. Customer to verify due diligence regarding install and warranty.

For more install instructions & tips please visit our YouTube channel @ Carven Exhaust.



Clamp Specs: Place top of clamp over non perforated section of tube, then slide clamp down to the slit section. Torque clamp bolt to 65LBS.

Parts Included:

- 3" band clamp QTY: 1

Step 1: OEM Removal

- Loosen clamps on OEM muffler and remove behind 3rd cat. Spray lubricant on exhaust hangers & remove spare tire for easier removal
- Stock exhaust can be removed in 1 piece if jack stands are utilized to gain clearance from chassis to the ground
 - Utilizing a car lift guarantees removal in 1 piece otherwise a Sawzall will be needed for cutting

Step 2: Installation

- Once OEM exhaust is removed move on to extension pipe
- Hang muffler using coupler clamp then adjust to fit snugly over extension pipe
- Keep wrap around tail pipe until installation is complete
- Hang tailpipe and use coupler clamp to snugly fit over muffler elbow section

Step 3: Fitment

- After all 3 pieces are installed and fit snugly, tailpipe with tips can be adjusted then tightened as well
 - When in desired placement, tighten all 3 clamps starting at 3rd cat ball clamp