



HUSKY SELECT™ FLOOR LINERS

PT #810058

USE AND INSTALLATION INSTRUCTIONS FOR YOUR FRONT FLOOR LINERS

Thank you for selecting a Husky Select™ Floor Liner from Husky Liners. Your new front floor liners are custom molded to fit your specific vehicle. The liners are made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liners.** However, *do not remove the factory-installed carpeting.* Your liners are made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liners is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liners slick.



LEFT OR DRIVER'S SIDE



RIGHT OR PASSENGER'S SIDE

TO EASE THE INSTALLATION OF YOUR FRONT LINERS, MOVE BOTH FRONT SEATS TO THEIR MOST REARWARD POSITION AND REMOVE ANY EXISTING FLOOR MATS. NOTE THAT THE DRIVERS SIDE LINER ATTACHES TO THE FACTORY FLOOR MAT RETENTION FASTENERS. SECURE LINER IN PLACE USING THESE FASTENERS.



HUSKY SELECT™ FLOOR LINERS

PT #810058

USE AND INSTALLATION INSTRUCTIONS FOR YOUR 2ND SEAT FLOOR LINER

Thank you for selecting a Husky Select™ Floor Liner from Husky Liners. Your new second seat liner is custom molded to fit your specific vehicle. The liner is made to take the place of your factory floor mat(s). **For correct fit, it is necessary to remove the factory floor mats before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Upon removal from the box your liner will not completely unroll and lay flat. This is normal and only temporary. Just place the liner on the floor or in the trunk of your vehicle with a weight in each corner (a book works well). After about 15 minutes, your liner will remain flat. In colder climates this “relaxing” may take longer; moving the liner to a heated area will accelerate the process.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.



TO EASE THE INSTALLATION OF YOUR SECOND SEAT LINERS, MOVE YOUR FRONT ROW SEATS COMPLETELY FORWARD AND REMOVE ANY EXISTING FLOOR MATS. INSTALL YOUR NEW LINERS, POSITIONING THEM IN THE VEHICLE AS SHOWN ABOVE. NOTE THE LOGOS WILL BE LOCATED NEAREST THE DOORS. LASTLY, REPOSITION YOUR FRONT ROW SEATS AS DESIRED.