

# THANK YOU FOR SELECTING A HUSKY FLOOR LINER FROM WINFIELD CONSUMER PRODUCTS

## CARE AND USE INSTRUCTIONS

---

Your new floor liner is custom molded to fit your particular vehicle. The liner is made to take the place of your factory floor mats. **For correct fit, it is necessary to remove the factory floor mat before installing your new floor liner.** However, do not remove the factory-installed carpeting.

Your liner is made from an engineering resin that is lightweight and extremely tough and durable. The easiest way to clean your liner is with a damp cloth or sponge. If using a cleaner, 409® or Glass Plus® work well. Use of Armor All®, Son-of-a-Gun® or similar items is discouraged as these products make the liner slick.

## INSTALLATION INSTRUCTIONS FOR YOUR FORD ECONOLINE VAN FRONT SEAT LINERS

**NOTICE: FITS MODELS WITH FACTORY CARPETING ONLY.**

WHEN INSTALLING YOUR PASSENGER SIDE LINER, YOU MAY NOTICE THAT IT DOES NOT MATCH WITH THE EXISTING INNER STEP. THIS FITMENT ISSUE IS DUE TO VARIATIONS IN VANS AND VAN CONVERTERS AND CAN BE EASILY REMEDIED WITH A SIMPLE TRIM. TO TRIM, REMOVE THE EXCESS PORTION OF YOUR LINER BY TRIMMING ALONG THE TOP OF THE RAISED RIDGE ON THE PASSENGER LINER AS SHOWN ON THE BACK OF THIS PAGE. A UTILITY KNIFE OR HEAVY SCISSORS WORK WELL FOR TRIMMING.



LEFT OR DRIVER'S SIDE

RIGHT OR PASSENGER'S SIDE

PASSENGER SIDE LINER SHOWN TRIMMED FOR NARROWER INNER STEP – USE THE GROOVE IN THE TOP OF THE RAISED RIDGE TO GUIDE TRIMMING. A UTILITY KNIFE OR HEAVY SCISSORS WORK WELL FOR TRIMMING. TRIMMING WILL NOT VOID THE LIFETIME WARRANTY.

