

CB Radio & Antenna Mount, JK



Components

- | | |
|---|-------------------------------|
| 1. CB Mounting Bracket.....(1) | 6. WM5 Well Nut.....(2) |
| 2. CB Antenna Mount.....(1) | 7. 8 x 40mm Hex Bolts.....(2) |
| 3. M5x20 Philips Head Machine Screw.....(2) | 8. 8mm Lock Washers.....(2) |
| 4. M5x12 Philips Head Machine Screw.....(2) | 9. 8mm Flat Washers.....(2) |
| 5. M5 Locking Hex Nut.....(2) | |

OMIX-ADA® TECHNICAL SUPPORT

PHONE: M-F 8am - 5pm EST 1-800-449-6649 | EMAIL: techsupport@omix-ada.com

FOR WARRANTY INFORMATION VISIT: www.Omix-Ada.com



OMIX-ADA, Inc.

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

CB Radio & Antenna Mount, JK

1. Position sun visors against side windows. Remove center portion of plastic windshield frame cover by gently pulling down until the clips release.



2. For **2007-2010** model JK's: drill out rivets using 3/8" drill bit. Rivets will be replaced with Well Nuts.

For **2011+** model JK's: remove the center footman loop by removing (2) Torx Screws.

NOTE: Be careful not to drill too deep, you may damage other side of windshield frame.



3. For **2007-2010** model JK's: insert the Well Nuts into the newly drilled holes in the sheet metal. If drilled holes are too large to snugly fit Well Nuts, secure with small amount of super glue.





OMIX-ADA, Inc.



460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

CB Radio & Antenna Mount, JK

4. For **2007-2010** model JK's: use provided M5x20 screws to install CB Mount and footman loop with CB Mount on outside.

For **2011+** JK's: use factory Torx screws to install CB Mount and footman loop with CB Mount on outside.



5. Replace center plastic windshield frame cover. Install CB Mount, radar detector, or GPS device using M5x15 bolts and Locking Hex Nuts.

NOTE: Make sure any installed devices are secure, and safe. Do not obstruct rear view mirror.



6. Remove the spare tire from your factory mount.

NOTE: The CB Antenna mount has (2) mounting holes. Either hole may be used.





460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

CB Radio & Antenna Mount, JK

7. Remove the (2) top right hand 13mm hex bolts from the spare tire mount.



8. Install the CB Antenna Mount using the supplied hex bolts, lock washers, and flat washers. Torque the bolts to 10 ft-lbs. Remount the spare tire after CB Antenna installation is complete.

