

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | info@omix-ada.com

IS-13752.35

Montana Soft Top with Door Skins, YJ

NOTICE

Ensure windows are kept clean to avoid scratching. **DO NOT** wash windows with brush. Wash with clean, watered-down cloth or sponge and mild detergent. **DO NOT** clean windows while dry. Use caution while cleaning in low temperatures as windows become more susceptible to scratching and cracking. **DO NOT** roll up windows in low temperatures as this causes windows to stiffen and crack. Windows should be clean when rolled up.

1. Remove side and rear windows. Remove tailgate bar from rear window and set aside for later use.



2. Unsnap center and rear cloth tabs from frame.





3. Pull down on spreader bars and push rear support bow forward.



4. Pull down and out on corners to release top from belt rail. Repeat for opposite side.



5. Unsnap soft top from above doors, remove front plastic strip from windshield channel, and remove soft top fabric.





6. Lay fabric top over frame and orient it on vehicle. Snap fabric to middle and rear bows.



7. Insert front top plastic strip into windshield channel retainer.



8. Push front support bow fully forward. Bow must slip into notch in belt rail. Pull bottom of rear bow forward to ease installation of side curtains.





9. Pull down and insert rear corners of soft top into belt rail.



10. Pull bottom rear support bow back until it snaps into notch in side rail.



11. Start zippers 2" to 3" on top and rear of side windows.





12. Slide plastic strip on front of side window into retainer channel on front support bow.



13. Slide plastic strip on bottom of side window into belt rail. Start at one end of window and work along vehicle to other end. Close top and rear zippers on side windows.



14. Push inner spreader bars up until they snap into place.





15. Install tailgate bar in receiver on each side of tailgate opening and slide rear window into tailgate bar. Start zipper of rear window. Hold up window and finish zipping rear window to top.



16. Fasten snaps on soft top, above doors, to studs on vehicle. Studs slide to match location of snaps on soft top.



Allow top to remain closed for several days with temperatures above 72 degrees Fahrenheit to allow top to stretch and set to frame.



17. Remove fabric upper doors from vehicle. Using razor blade, cut stitching on old door covers and remove from frame.





18. Separate hook and loop fasteners on new door skins. Lay door skin on flat surface with outside facing down. Start by working lower rear corner of door frame into pocket in lower rear corner of door skin. Continue working door skin around frame and fasten hook and loop strips as you go.



19. Reinstall upper doors. Insert pins into grommets in lower doors. Fasten snap at front of upper door. Slip plastic strip on bottom of door skin into retainer on lower door.

