



NOTE: Please read complete instruction sheet before installing.

Step One: Check part numbers listed below with component received.

QTY	DESCRIPTION
1	Hitch Step Stainless or Black
1	Plastic Shim with Tape
1	Hitch Pin & Clip

Step Two: Position the hitch step to the vehicle hitch receiver.

Step Three: Wedge shim between receiver and Hitch Step. Mark location on the bottom of the Hitch Step. (Fig # 2)

Step Four: Attach shim to Hitch Step where you have marked. **Note:** Use rubbing alcohol to clean wax from the area where the plastic shim will attach to the Hitch Step. Keep Shim dry for 24 hours to enable the adhesive to fully cure.

CAUTION:

ALWAYS SECURE THE STEP TO YOUR RECIEVER HITCH WITH THE PROVIDED HITCH PIN

Please take care when assembling and installing this product to protect the finish and your investment. To protect your investment, wax this product after installing. Regular waxing is recommended. Do not use any type of polish or wax that contains abrasive that could damage the finish.