




INSTALLATION INSTRUCTIONS

HAVOC HS3

NERF BAR WITH STEP

HPG-003134

2011-2014 GM HD CREW CAB 6'6" BED SRW W/ DIESEL ENGINE



WATCH THIS INSTALL,
Scan here or enter this
URL address to view,

<https://www.youtube.com/watch?v=n0VUaMmOqFI&feature=youtu.be>



(This video is of HS2 Crew Cab install of 2015-current, this video uses similar steps. In the video the first passenger bracket is two pieces and this model there is only a one piece bracket.)

Hardware:

Zinc 8mm U-Nut - 20mm center of hole to edge	7	Black 8mm Washers - 16mm OD.....	10
Zinc 8mm Hex Bolt - 1.25 x 25mm.....	7	Black 8mm Serrated Flange Nut.....	7
Zinc 8mm Washer - 22mm OD.....	13	Black 10mm Hex Bolt - 1.50 x 30mm.....	1
Zinc 8mm Lock Washer.....	7	Black 10mm Washers - 28mm OD.....	1
Zinc 8mm Serrated Flange Nut.....	6	Black 10mm Lock Washer.....	1
Black 8mm Hex Bolt - 1.25 x 25mm.....	8	Black 10mm Serrated Flange Nut.....	1

STEP 1:

Insert spring loaded
U nuts to the body
of the truck.



STEP 2:

Carefully place HS3
step into place. Use Zinc
8mm bolt, washer and
begin hand tightening all
upper mountings (4 on
drivers side and 3 on the
passenger side). Best to
have a assistant to lift
and hold board in place.



STEP 3:

Insert black 8mm head
bolt and washer through
pinch weld hole and
secure with serrated
nut and washer. The
first location on the
passenger side will use
the 10mm hardware
instead.



STEP 4:

**Avoid using power or
air tools.** Tighten pinch
weld mounts first then
upper bolts. Tighten to
20ft lbs torque to secure
the board to the truck.