



## **Differential Fill Plug reminder:**

### **Part numbers:**

- 11118.02 – Stainless Dana 30**
- 11118.02 – Stainless Dana 30 , 41-86 CJ**
- 11118.03 – Stainless Dana 44**
- 11118.05 – Stainless Dana 35**
- 16595.20 – H/D AMC 20**
- 16595.30 – H/D Dana 30**
- 16595.44 – H/D Dana 44**
- 16595.35 – H/D Dana 35**
- 15595.60 – H/D Dana 60**

- (1) When installing a new differential cover make sure you have properly removed any and all gasket material from the differential mating surface. It is also important to avoid scraping or gouging this surface to insure a tight leak free installation when combined with correct gasket or RTV sealant.
- (2) When installing the fill plug, after gear oil has been added, it is a good idea to apply a small amount of Teflon tape to the fill plug to help insure a tight leak free fitment.

