

## Third Brake Light Spacer, TJ & LJ

### Contents :

- |                                   |     |
|-----------------------------------|-----|
| 1. TJ Brake light extension plate | (1) |
| 2. Hex Bolts                      | (4) |
| 3. Flat washers                   | (4) |
| 4. Fender washers                 | (4) |
| 5. Nylon lock nuts                | (4) |

### Required Tool :

1. 13 mm. wrench



1. Unmount spare tire.  
Remove factory bolts that secure brake light tower.



2. Place Brake light extension on rear tire mount with triangle cutout facing front of vehicle.



OMIX-ADA® TECHNICAL SUPPORT

PHONE: M-F 8am - 5pm EST 1-800-449-6649 | EMAIL: techsupport@omix-ada.com

FOR WARRANTY INFORMATION VISIT: [www.Omix-Ada.com](http://www.Omix-Ada.com)

Copyright © 2013 Omix-Ada®, Inc.



OMIX-ADA, Inc.

460 HORIZON DR. SUITE 400 | SUWANEE, GA 30024 | PHONE: 770-614-6101 | FAX: 770-614-6069 | [info@omix-ada.com](mailto:info@omix-ada.com)

## Third Brake Light Spacer, TJ & LJ

3. Use factory bolts (Removed in step 1) to attach brake light extension to rear tire mount.



4. Attach brake light tower to brake light extension with supplied hardware.



5. Reinstall the spare tire.



OMIX-ADA® TECHNICAL SUPPORT

PHONE: M-F 8am - 5pm EST 1-800-449-6649 | EMAIL: [techsupport@omix-ada.com](mailto:techsupport@omix-ada.com)FOR WARRANTY INFORMATION VISIT: [www.Omix-Ada.com](http://www.Omix-Ada.com)

Copyright © 2013 Omix-Ada®, Inc.