

21120/21120B
2014 CHEVROLET
SILVERADO 1500 Z71



21120/21120B
2014 CHEVROLET
SILVERADO 1500 Z71

2014 CHEVROLET SILVERADO 1500 Z71

Billet Grille 2 Pc

TOOLS REQUIRED:

Flat/Phillips Screwdrivers

PARTS LIST

- (1) 2 pc. grille
- (6) Black Toggle Wings
- (6) 6/32" X 2" Machine Screws



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION. Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquiries can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1 Grille Installation

Take the two billet grilles and locate the small square tab with a hole in the center that are welded to the back of the billet grilles (Fig 1). From the front of the billet grille insert the machine screws through the billet bars and the small square tab, install the toggle wings onto the screws a couple of turns (Fig 2). Take the billet grilles and insert them into the appropriate opening in the factory grill. Use a small screwdriver to reach through the billet bars and turn the toggle wings vertically while tightening them with a phillips screwdriver (Fig 3). Installation complete. Thank you for purchasing a T-REX Grille.

