

25638
2010-2011
MAZDA CX7



25638
2010-2011
MAZDA CX7

2010-2011 MAZDA CX7

Bumper Billet

TOOLS REQUIRED:
8mm Socket and Ratchet
Flathead/Phillips Screwdriver

PARTS LIST
(6) 2" Flange Brackets
(6) #8 U-Nuts
(6) 1 3/4" #8 Screws

(1) Billet Bumper Grille



PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE INSTALLATION.

Auto makers offer varied models to each vehicle and occasionally manufacture more than one body style of the same model. To assure your part is correct; our tech department can be contacted at tech@trexbillet.com to verify fitment or assist with tech questions. All other inquires can be directed to info@trexbillet.com. In the event you do not have internet access please call 1-800-287-5900.

Step 1

Install the u-nuts onto the flange brackets (Fig 1). From underneath the vehicle remove two 10mm bolts from the plastic cover underneath the front of the vehicle (Fig 2) and remove the plastic cover. This will give you access to the backside of the bumper.

Step 2 Install Billet

Take the billet and insert it into the factory bumper opening. Take the screws and insert them through the billet bars and the small square tabs with a hole in the center that are welded onto the backside of the billet (Fig 3). From the backside of the bumper install the flange brackets with the u-nuts and place them onto the screws (Fig 4) tighten the screws. Replace the bottom plastic cover. Installation complete.



Fig 1



Fig 2



Fig 3



Fig 4

Thank you for purchasing a T-Rex Grille.

Rev. 08/03/10