

25938
25938B
12-13 TOYOTA
TACOMA



25938
25938B
12-13 TOYOTA
TACOMA

12-13 TOYOTA TACOMA

Upper Class Billet Grille

Install time: 20 Mins.

TOOLS REQUIRED:

Socket Wrench

PARTS LIST:

(1) Bumper Billet Grille (2) 2 1/2" Screws
(2) 1/2 x 1/2 L-Brackets
(2) U-Nuts

PLEASE READ AND UNDERSTAND ALL INSTRUCTIONS
BEFORE ATTEMPTING INSTALLATION.

**IF YOUR HANDS REACH FROM BEHIND THE BUMPER SKIP
TO FIG. 2**

- Remove 2 Bolts and 1 Clip along the top of the Factory Grille. (Fig.1)
- Unclip 8 Clips along the Bottom of the Factory Grille to Remove.
- Place a U-Nut onto the L-Bracket with the Hole. (Fig. 2)
- Place Bumper Grille onto the Factory Bumper Opening. (Fig. 3)
- Insert the 2 1/2" Screw through the Bracket on the Billet Grille. (Fig. 4)
- From behind the Grille, Thread the L-Bracket onto the Screw so it Latches onto the Factory Grille. (Fig. 5)

Installation Complete

