

35716

03-06 LINCOLN

AVIATOR

BILLET BUMPER

VERTICAL



35716

03-06 LINCOLN

AVIATOR

BILLET BUMPER

VERTICAL

Tools Required:

Phillip Screw Driver
Drill
1/8" Drill Bit

Hardware / Parts Included:

1 - Bumper Billet Insert (44 Bars)
5 - #8 x 1 Screws (#6 Head)

Read and understand instructions before attempting installation

Step 1

Remove the license plate assembly from the vehicle.

Step 2

Center the insert in the bumper opening. Make sure the insert is correctly aligned. Mark where each mounting tab aligns on the opening. Remove the insert and drill a 1/8 hole at each mark. Center the insert and drill a 1/8" hole at each mark. Install a screw at each mounting tab. **Do not over tighten the screws!**

Step 3

Make sure the fasteners are tight. Replace the license plate assembly on the vehicle.
Thank You for purchasing a T-Rex Billet Grille!