

57187, 57186
52187
10-13 Cadillac
SRX



57187, 57186
52187
10-13 Cadillac
SRX

10-13 Cadillac SRX
Upper Class Bumper

TOOLS REQUIRED:

- Socket & Ratchet Set
- Screwdriver Set
- 3/4 Drillbit & Drill

PARTS LIST

- (1) Bumper Grille
- (4) L-Brackets
- (4) 6/32 Nylon Lock Nuts

BUMPER GRILLE REMOVAL

- With a 3/4 Drillbit, Drill through the center of the Screws on the License Plate and remove. (Fig. 1)
- Remove 3 Silver Bolts towards the end of the Bumper Cover. (Fig. 2)
- Remove 2 Clips from each Side Fender Well. (Fig. 3)
- Remove 12 Bolts on the Inner Bumper Shell between the Outer Bolts. (Fig. 4)

BUMPER GRILLE INSTALLATION

- Place Mesh Grille Through the Factory Bumper Opening. (Fig. 5)
- From behind, Place an L-Bracket on the Threaded Studs on the Mesh Grille and Tighten with provided 6/32 Nylon Lock Nuts. (Fig. 6)

INSTALLATION COMPLETE

