



# Door Handle Cover Installation Instructions



PATENT(S): This Product is covered by one or more patents. Visit [trimillusion.com/patents](http://trimillusion.com/patents) or scan QR code for active unexpired patent info.

1. Carefully test fit product on application site before removing the double-sided tape or the protective film



Some of our door handles are installed using our patented “Snap-On” technology. When test fitting, they may appear to not fit, hold the covers next to the door handles to confirm they are the same. Be sure not to push handle covers fully into place before removing double-sided tape film.

2. Inspect application site to make sure it is free of dirt, oil, grease, or wax. Clean the application site with water-based solutions like Isopropyl Alcohol or Windex to avoid damaging the finish then dry the surface well.
3. Apply included or preferred adhesive promoter to application site. Promoter is only needed on areas that will contact the tape.
4. Remove protective film from double sided tape. In case of
5. Carefully align product on application site, pressing firmly over entire site to ensure proper adhesion.



Snap-On door handle covers will need to be pushed onto the handle until they snap into place



**Please read instructions carefully before installing.**



**For best results, do not attempt installation in cold temperatures. Install in 50°F or above for glue to properly adhere part to surface.**