



Trim IllusionTM
Automotive Accessories

Overlay Accessory Installation Instructions

1. Carefully test fit chrome product on application site before removing the double-sided tape or the protective film. If you suspect fitment to be incorrect, contact us immediately and share supporting images.
2. Inspect application site to make sure it is free of dirt, oil, grease, or wax. Clean the application site with water-based solutions like Windex to avoid damaging the finish then dry the surface well.
3. To start the installation, make sure you are in a 50°F or above environment for glue to properly adhere part to surface. Apply included or preferred adhesive promoter to application site.
4. Remove protective film from adhesive compound. In case of residue on the chrome finish, please use a microfiber cloth and alcohol to clean the surface.
5. Carefully align chrome product on application site, pressing firmly over entire site to ensure proper adhesion. If you make a mistake, you can use a heat gun or blow-dryer/hairdryer to loosen adhesive to remove the part from application site. Also, double-sided tape or promoter (sold in hardware stores) can be reapplied or added to missing areas if necessary.
6. Subscribe to our YouTube channel “Trim Illusion” to view a variety of helpful installation videos.