

# Running Board Instructions

## 2070

( 06 – 10 ) Dodge Ram Mega Cab

( Minor Drilling Required )

### INSTALLATION PACKAGE

Running Board	2
Bracket s Front	2
Brackets Middle	4
Bracket s Rear	2
Support Plate Front	2
Support Plate Rear	6
Bolt Plate	8
Bolt Packs	2

### Necessary Tools

Ratchet wrench with 1/2" & 13 mm socket  
 Combination wrench  
 Variable speed drill w/ 3/8" hex head drive  
 Safety glasses

### Bolt Pack Brackets

5/16" x 3/4" Hex Bolt	24
5/16" Flat washer	24
5/16" Serrated Flange Nut	32

### Bolt Pack Running Boards

5/16" x 3/4" Hex Bolt	16
5/16" x 3/4" Serrated Flange Nut	16

### STEP ONE : Determine proper bracket placement Fig A & B & C

1. There are ( 4 ) places on the inside of the rocker panel were the brackets need to be placed. ( Locate the factory holes as indicated Fig A .
2. Insert carriage bolt mounting plates as indicated Fig B
3. Loosely bolt ( hand tighten ) brackets on the inside of the rocker panel factory holes, As shown Fig C with flange nuts. ( Be careful not to drop in mounting plates. ) (2) front brackets have bent tip on top (2) rear brackets are shorter than (4) middle brackets
4. Do this with all brackets putting them in there proper place.
5. With brackets mounted in vertical position. Mount pinch weld mounting plates (2) front & (6) rear to brackets using supplied 5/16" fasteners.
6. Locate and mark holes on pinch weld and drill 5/16 clearance holes ( Use pictures to show support plate on inside or outside of pinch weld ) Fig C
7. Fasten support plate to pinch weld with 5/16" bolts and flange nuts. Hand tighten to bracket to allow for later adjustment up and down.

### STEP TWO : Board Installation & Check.

- 1) Place board on brackets by sliding mounting bolts in slots on underside of boards and allow bolt thread to drop through bracket slots. With brackets mounted in position, slide 5/16" bolts down outside channels on underside of board so bolt studs will line up with bracket slots and install board on brackets. It is only necessary to use one bolt to hold board on each bracket if only one slot lines up.
- 2) Check board for levelness and snug fit to vehicle. Tighten outside brackets first then adjust inside bracket accordingly. Adjust and fully tighten all brackets.
- 3) Check all bolts to verify completed mounting and tightness. Installation is complete

